


#### Merco Eco and MercoMax Timer Bar Menu Connect

# Original Instructions Internet-Based Software Instructions

This manual is updated as new information and models are released. Visit our website for the latest manual.





Part Number: MER IOM 8197470 08/2020



#### **Table of Contents**

| Section 1<br>General Information |   |
|----------------------------------|---|
|                                  | Software Requirements1-1  |
| Section 2<br>Software            |   |
|                                  | Software Access, Navigation, Loading Configurations2-1                  |
| Section 3 Software Interface     |   |
|                                  | Annotated Product Editing Screen3-1 Annotated Tray Assignment Screen3-2 |
| Section 4 Configuring Cabinets   |   |
|                                  | Loading Configurations on Cabinet4-1                                    |
| Section 5<br>Adding Items        |   |
|                                  | Adding Food Items to Menu Configurations5-1                             |
| Section 6                        |   |
| Timer Bars                       | Reconfiguring Cabinets with Timer Bars6-1                               |
| Appendices                       | Software Shortcuts and Hints  |

#### Section 1 General Information

#### **Software Use**

This software is used to create cabinet configurations exclusively for Merco Eco and Merco Max holding cabinets with timer bars. These configurations are used on cabinets not connected to a monitoring network. It is accessible on the Internet, by visiting: <a href="https://www.welbiltdigital.com">https://www.welbiltdigital.com</a>

You will need to register by creating a username and password and providing basic information.

This software is compatible with OS Windows XP or greater. (Not recommended for use with iOS systems at this time.)

To use files created by the Internet-based MenuConnect software, the cabinet must have these software versions loaded:

• I/O: v01:06:01


• Timer bar: v00:02:03

• Display Board: v01:00:00

If the cabinet was manufactured after October 2017, it will already have the correct software version. (s/n starts with: 1711-1712, 1801-1812, 1901-1912, 2001-2008, etc). If the cabinet was manufactured prior to these dates, the software version is downloadable from the Support Tools tab on the MenuConnect Product Details screen.


Updating the cabinet's software also introduces a Timer Barbased programming function.







Tech Service contact info 877.392.7770

#### Section 2 Software Access, Navigating Interface, Configuring Cabinet







### Section 3 Software Interface



| Thi | This screen appears when the software is launched and when the Tray Assignments button is pressed.                   |  |  |  |
|-----|--|--|--|--|
| 1   | Product Details: Current view. This is where food items are entered or edited.                                       |  |  |  |
| 2   | Tray Assignments: Use to populate a cabinet and save and export menu file  |  |  |  |
| 3   | Support Tools: Access manual, software.  |  |  |  |
| 4   | <b>Pencil Icon</b> : Press to edit holding parameters for item.  |  |  |  |
| 5   | <b>Trash Can Icon</b> : Press to eliminate food item.  |  |  |  |
| 6   | <b>Celsius</b> : Press to display temperatures in Celsius.   |  |  |  |
| 7   | Fahrenheit: Press to display temperatures in Fahrenheit.   |  |  |  |
| 8   | <b>Product Name</b> : Complete product name entered when a product is added. It's not displayed on the cabinet.      |  |  |  |
| 9   | <b>Product Short Description</b> : Abbreviated product name. It's displayed on the cabinet.                          |  |  |  |
| 10  | Holding Time: Total holding time for product.  |  |  |  |
| 11  | Upper Temperature: Setpoint temperature of upper heater.   |  |  |  |
| 12  | Lower Temperature: Setpoint of lower heater.   |  |  |  |
| 13  | Cook More Alert: User-defined alert displayed as a product nears expiration.   |  |  |  |
| 14  | <b>Add Menu Item:</b> Press to bring up screen to enter a new product. See Section 5.                                |  |  |  |
| 15  | <b>Restore Default Menus</b> : Press to return to default factory menu settings. Eliminates hand-entered menu items. |  |  |  |






# Section 4 Loading Configurations on Cabinet

| 1      | Start cabinet and allow cabinet's displays to reach preheat, alternating with product names. Ensure no zones are timing product.   |                   |
|--------|--|-------------------|
| 2      | Insert flash drive with menu configurations into the USB port.   |                   |
| 3      | Cabinet with timer bars: SELECT is displayed on leftmost display. The adjacent display scrolls cabinet names from the files on the flash drive.  Cabinets without timer bars: Files names appear on the display and are scrolled with the keypad's + and - keys. | • SELE CT •       |
| 4      | Scroll with the up or down arrow keys on the display or the + and - keys on the keypad.  Mismatched cabinet size/menu file configurations are not allowed. <b>See Note 1</b> .   | • CABIN ET 1 •    |
| 5      | Press the von the keypad when the desired configuration is shown.  | *                 |
| 6      | A successful configuration load is noted by MENU UPLOAD SUCCESSFUL on the display.   | • SUCCE SSFUL •   |
| 7      | Press the ✓ and remove flash drive.  |                   |
| Note 1 | If the selected configuration is the wrong size for the cabinet, INVALID FILE is shown. The flash drive must be removed, the cabinet restarted and the process started over at Step 2.   | • INVAL ID FILE • |

## Section 5 Adding Menu Items



Press the Add Menu Item button on the Products Detail page (see inset) to open the Add Menu Item dialog box. Follow the steps below to enter the data. The cabinet can hold 100 menu items. The new items will be available for selection when the new menu is loaded on the cabinet.

| 1 | <b>Product Name</b> : Enter name, up to 25 characters, that will be shown on the Products Detail page.   |  |
|---|--|--|
| 2 | <b>Product Short Description</b> : Enter the abbreviated name, up to four characters, that will be displayed on the cabinet.   |  |
| 3 | <b>Holding Time</b> : Enter holding time for the product. The range, in minutes, is 1-1,440.   |  |
| 4 | <b>Upper Temperature:</b> Enter temperature, between 155-250, for the upper heater setpoint. Choose a temperature that's compatible with other products.                                       |  |
| 5 | <b>Lower Temperature:</b> Enter temperature, between 155-250, for the lower heater setpoint. Choose a *temperature that's compatible with other products.                                      |  |
| 6 | <b>Cook More Alert:</b> Enter the number of minutes from the expiration of the hold time a Cook More Alert should be displayed.  |  |
| 7 | Reset: Empty Add Menu Item dialog box.   |  |
| 8 | <b>Add Menu Item</b> : Press to add entered item to menu, which will be accessible from the Products Detail page. The cabinet, which is loaded with 30-plus default items, can hold 100 items. |  |

<sup>\*</sup> New products must have the same holding temperatures as existing products they are to share a zone with.

# Section 6 Rearranging Menu Items in Dayparts Using the Timer Bars

Follow these steps to change displayed menu items on a configured cabinet equipped with timer bars. All food items that are saved in a menu file will be available to choose using this method.

| 2                                 | Press the Program button and then Press and hold the Day Part button until the Day Part LED flashes, about three seconds.  See Note 1 to halt programming and discard changes.  See Note 2 to change a position to None.  Press the timer button next to a product to be       | (a) (b) (c) (d) (d) (d) (d) (d) (d) (d) (d) (d) (d   |
|-----------------------------------|--|--|
| _                                 | changed. That product flashes. Items in the same zone remain solid. Other displays go blank.   | CHILE P  |
| 3                                 | Use the + or - key on the keypad to scroll through products on the flashing display.   | * db 12.3 12.3 12.3 12.3 12.3 12.3 12.3 12.3   |
| 4                                 | If the product is incompatible with items in the same zone, LED's on the shared zone turn red, the position being programmed flashes the product name, the display text dims.  If the ✓ is pressed, Temp Mismatch scrolls one time. <b>See Note 2</b> to set position to None. | •• BURG •• CHIL  |
| 5                                 | Scroll to the desired compatible products with the keypad's + or - key. The displays' LED's turn green. Press the keypad's ✓ to save the change. The new product is shown and other displays associated with other zones repopulate.   | ·• BURG  |
| 6                                 | Program another timer button on the current Day Part display in the same way or move to another Day Part for programming by scrolling with the Day Part button.  Repeat steps 2-5 to program other items.  | * * * * * * * * * * * * * * * * * * *  |
| 7                                 | With all the changes complete, press the Program key. Save and Exit is displayed in leftmost position. Press v to save and exit.  See Note 1 below to discard changes and exit programming.  | (a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c   |
| the X bu<br>The disp<br>Press the | inet returns to its normal mode and the changes are  | Note 2: With incompatible items displayed as described in Step 4, press and hold the + or - key for three seconds. The position being programmed becomes and continues to flash.  Press ✓  Press Programming key  Press ✓. |

## Appendix A Software Shortcuts, Hints

The sign-on for the software interface is unique. Each user can have up to 10 named cabinet configurations saved on the site. The Cabinet 4 Cabinet 5 Cabinet 5
Cabinet 6
Cabinet 7
Cabinet 8
Cabinet 9
Cabinet 10 configurations don't have to be rebuilt at each sign on. 2 The Copy From feature allows pre-configured Day Parts to be copied and moved to a Day Part that requires revision with the same or a very similar configuration. Select the Day Part that is to be populated. Select the Day Part to be copied in the Copy From pulldown. Press Copy. Change the few items necessary to complete the new Day Part. Give menu files meaningful names, including 3 cabinet size, to ease configuring cabinets. Up to 20 Cabinet 4 3x2.cbr files can be kept on a flash drive. Cabinet 3 4x2.cbr Cabinet 2 3x4.cbr Cabinet 1 2x4.cbr



Serving Quality on Demand

800.221.4583 CUSTOMER SERVICE 877.392.7770 TECHNICAL SERVICE WWW.MERCOPRODUCTS.COM



#### WWW.WELBILT.COM

Welbilt provides the world's top chefs, and premier chain operators or growing independents with industry leading equipment and solutions. Our cutting-edge designs and lean manufacturing tactics are powered by deep knowledge, operator insights, and culinary expertise.

All of our products are backed by KitchenCare® – our aftermarket, repair, and parts service.

► CLEVELAND

► CONVOTHERM®

DELFIELD®► FITKITCHEN™

▶ FRYMASTER®▶ GARLAND

► KOLPAK®
► LINCOLN

► MANITOWOC®

► MERCO®

► MERRYCHEF®
► MULTIPLEX®